



Samsung Galaxy J1 Logic Board, Main Camera, Front Camera, Earpiece, Loudspeaker Replacement

Samsung Galaxy J1 Logic Board, Main Camera, Front Camera, Earpiece, Loudspeaker
Replacement

Written By: ZFix



INTRODUCTION

How to disassemble Samsung GALAXXY J1 / SM-J100

[video: <https://www.youtube.com/watch?v=Doj2ymukO2A>]



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 05:13:12 AM.